



DELTRON® Reducer Selection Guide

National Rule



The below recommendations are only a general reference and should be used solely as a starting point for choosing the appropriate reducer. Your particular spray environment and job size may require slight adjustments.

Temperature

| 60°F (15°C) | 65°F (18°C) | 70°F (21°C) | 75°F (24°C) | 80°F (26°C) | 85°F (29°C) | 90°F (32°C) | 95°F (35°C) | |
|----------------|---|----------------|---|---|---|---|---|--|
| | DT870 <i>Primer / Sealer / Basecoat</i> | | | | | | | |
| | | | DT885 <i>Primer / Sealer / Basecoat</i> | | | | | |
| | DT870 <i>Clearcoat / Single Stage</i> | | | | DT895 <i>Primer / Sealer / Basecoat</i> | | | |
| | | | DT885 <i>Clearcoat / Single Stage</i> | | | | DT898 <i>Primer / Sealer / Basecoat</i> | |
| | | | | DT895 <i>Clearcoat / Single Stage</i> | | | | |
| | | | | | | DT898 <i>Clearcoat / Single Stage</i> | | |
| | | | | | | | DT8110* <i>Clearcoat / Single Stage</i> | |
| | | | | | | | *must be mixed with DT8xx reducer | |

Tips:

- A higher temp reducer in a clearcoat will allow the surface to stay open longer and provide additional leveling.
- Consider the job size when selecting the appropriate reducer. Larger jobs may require a higher temp reducer in order to maintain a "wet" edge.
- Where there is excessive air flow in the spray area, a higher temp reducer should be considered to minimize the potential for solvent entrapment.